

WALL GRIP™



INSTALLATION GUIDE

GETTING STARTED

WallGrip should be laid flat and acclimated for a minimum of 24 hours with room conditions between 65°F and 85°F (18°C and 29°C).

The surface must be smooth, flat and dry, free of dirt, dust, wax, grease, and other contaminants.

Approved substrates are beadboard, cement board, glass, ceramic tile, plywood (A.P.A. approved BB or better), wood paneling, concrete (must be smooth, flat, dry, and sealed), sheetrock (must be primed or painted with flat latex paint).

KILZ 2® ALL-PURPOSE Primer (Previously KILZ 2 Latex), or equal, works as a primer.

If in doubt, do a test area prior to installation.

Not for use in wet areas.

TOOLS NEEDED

- Level
- Tape Measure
- Utility Knife
- Pencil or Marking Chalk
- Hand roller

INSTALLATION

- 1.) If applying above a base board, ensure that the wall is level.
- 2.) Peel the paper backing from the plank/tile, making sure to remove the entire sheet.
- 3.) Position one end of the WallGrip where you want and press down. Apply firm pressure across the plank/tile as it adheres to the wall. Use a hand roller to insure the adhesive is bonded to the wall.
- 4.) When you reach the edge of the wall, measure the area and use the same measurement to mark the plank/tile. Use a utility knife to trim WallGrip to fit.
- 5.) Offset planks/tiles in each row to achieve a staggered installation.