floorfolio®

LVW™
LUXURY VINYL WALLS

INSTALLATION GUIDE

KEY NOTE Use only an adhesive approved for both the vinyl panel and the wall substrate. Follow the panel, adhesive, project, and code requirements for the specific installation.

RECOMMENDED TOOLS Tape measure | level or laser | pencil | straight edge | cutting tool | adhesive applicator | wall or seam roller | clean cloths | PPE

1 CONDITION THE MATERIALS AND ROOM

- Store and acclimate panels and adhesive as their manufacturers direct. Keep panels protected from damage and distortion.
- Maintain normal occupied temperature and humidity before, during, and after installation.

2 PREPARE THE WALL

- The wall must be dry, smooth, clean, structurally sound, and free of dust, grease, loose paint, wallpaper, and other bond breakers.
- Fill and smooth holes, joints, and high spots. Prime only when required for the wall or adhesive system.

3 PLAN THE LAYOUT

- Measure the wall and panels. Mark level and plumb starting lines, then dry-fit the first panels before applying adhesive.
- Plan seams, corners, and cutouts. Leave any perimeter or expansion space required by the panel manufacturer.

4 APPLY THE ADHESIVE

- Spread the approved adhesive evenly with the recommended applicator. Follow its coverage rate, open time, and working time.
- Apply only as much adhesive as can be covered within the stated working time.

5 PLACE AND ROLL THE PANELS

- Set the first panel on the reference lines without dragging it through the adhesive. Press from the center toward the edges.
- Roll the full panel with the recommended roller, paying close attention to edges and seams. Install remaining panels consistently and clean fresh adhesive immediately with an approved cleaner.

6 FINISH, CURE, AND INSPECT

- Install specified trims. Sealseams, corners, and perimeters only where required, especially in wet or hygiene-sensitive areas.
- Protect the wall until the adhesive has fully cured. Do not wash, load, or disturb panels during curing. Inspect and correct bubbles, loose edges, or adhesive residue before use.

SAFETY + LIMITATIONS Wear appropriate PPE and provide ventilation. Confirm utilities before cutting near outlets or pipes. Do not install over damp, unstable, contaminated, or deteriorated walls. Test cleaners and sealants in an inconspicuous area before use.

GENERAL GUIDANCE: Site conditions and products vary. The panel manufacturer's current instructions, the adhesive manufacturer's instructions, approved project documents, and applicable building and fire codes govern the installation. Contact us at: **LVW@floorfolio**.com for more information or if you have questions.

FloorFolio Industries
110 Mayfield Ave | Edison, NJ 08837
(800) 671-1124 | LVW@floorfolio.com
Luxury Vinyl Walls Quick Install Guide
Rev. 8.2026