

FloorFolio EnviroQuiet 5.0 Rubber Backing / Roller Chair Test

Roller chair test plaques were prepared over porous substrate (SurePly® Underlayment) with FloorFolio 9100 Acrylic Adhesive using a 1/16" x 1/16" x 1/16" Square-notch trowel. Plaques were heat aged for 14 days at 120° F then tested for 25,000 cycles. Results are listed below.

Roller Chair (TM-010)							
Adhesive	Flooring	Trowel	Application	Delamination	Indentation	Telegraphing	Adhesion
FloorFolio 9100	EnviroQuiet 5.0	1/16" Square-Notch	Dry-Set	No Delamination	No Indentation	No Telegraphing	Excellent

EQ
EnviroQuiet® 5.0



FloorFolio 9100

If you have questions or need additional information, contact FloorFolio's technical department.

FloorFolio 5.0 Rubber Backing/Roller Chair Test

Rev. 1.21