



INSTALLATION GUIDE

GETTING STARTED

WallGrip should be laid flat and acclimated for a minimum of 24 hours with room conditions between 65°F and 85°F (18°C and 29°C).

Prepare an ideal wall surface by making sure it is clean and dry.

TOOLS NEEDED

- Level
- Tape Measure
- Utility Knife
- Pencil or Marking Chalk
- Hand roller

INSTALLATION

- 1.) If applying above a base board, ensure that the wall is level.
- 2.) Peel the paper backing from the plank/tile, making sure to remove the entire sheet.
- 3.) Position one end of the WallGrip where you want and press down. Apply firm pressure across the plank/tile as it adheres to the wall. Use a hand roller to insure the adhesive is bonded to the wall.
- 4.) When you reach the edge of the wall, measure the area and use the same measurement to mark the plank/tile. Use a utility knife to trim WallGrip to fit.
- 5.) Offset planks/tiles in each row to achieve a staggered installation.